

# SHENGZHOU HUIMEI INTERNATIONAL TRADE CO.,LTD

ADD: DONGXI BRIDGE, GANLIN TOWN, SHENGZHOU, ZHEJIANG, CHINA

TEL: 0086 575 83061938; FAX: 0086 575 83068938

Thank you for purchasing SSM wood stove S26-13. Please read this document carefully, follow the safety instructions before using the stove for the first time.

## SPECIFICATION



Item	Part name	Description
1	Stovetop	Cast iron, dia. 32cm
2	Combustion Chamber	Ceramic chamber with 1mm stainless steel liner Grade201
3	Stove body	0.5mm stainless steel, Grade 201
4	Handle	Easy to move the stove
5	Stick support	Feeding the firewood.
6	Thermal Power	4kw
7	Thermal efficiency	38.7% with pot skirt

Size: 320\*320\*267mm , Weight:10 kg

## WARRANTY

1. Lifespan: 5 years based on proper usage and maintenance.
2. In the case of normal use, a warranty period of two year will apply to our stove from the date of purchase.

3. The warranty does not cover improper use or misuse of the rocket stove. Opening or dismantling the stove invalidates the warranty.

## SAFETY INSTRUCTIONS

1. The stove is a cook appliance for outdoor use only, not a space heater. Never use indoors because of Fire Hazard and danger of suffocation.
2. Comply with fire safety regulations. Show consideration to the plant and animal life and to nature reserves when using the stove.
3. Keep a safety distance to flammable and heat-sensitive objects.
4. Place the stove on a level, not heat-sensitive surface and make sure that it is steady. When putting cookware on the stove, avoid rickety structures.
5. Wear right clothes when using the stove. Avoid wearing long, loose sleeves.
6. We recommended that a lighter with a long handle be used to ignite the fuel. Not use liquid fuels such as gasoline or alcohol as the firelighter.
7. **Keep and store out of reach of children. This product is not intended for use by children, and is not child proof.**
8. Never leave stove unattended when hot or in use.
9. Do not move the stove when it is burning or in operation, It could cause burns.
10. Avoid touching any part of the stove when it is burning.
11. Let the rocket stove completely cool down after use.

## How to use

Step1, Take out the stove and the stick support from the box, put the stove on the floor steadily.

Step2, Place the stick support in installation sockets. Make sure the left socket and right socket suit for the stick support.

Step3, Put 3-4 small sticks on the stick supports and then ready to start the fire.

Step4, DON'T use too many sticks.

Step5, Light the fire and ready to cook

Step6, Put a pot on the stove top and enjoy cooking.

After each use, empty the ashes and wipe outside of the stove. Make sure the stove is clean enough to cook for the next time.